# INSTALLATION MANUAL
# S21/Mod 20/Mod 32

This installation manual demonstrate a right-hinged cabinet.

(For left hinged cabinet recommended water supply in opposite corner.)

NB. Heater installation instruction is delivered seperate


## NOHA Norway AS

Pb. 8126 Forus, 4069 Stavanger
Lagerveien 25, 4033 Stavanger
Tel. +47 51 81 60 00 Fax +47 51 81 60 01





1







2




3




English
Stick the service-label and the valve instruction sign on the wall. Valve sign to be as close to the valve as possible.

Function-test. Close the nozzle, open the valve and run out the whole hose. Make sure the installation is free for leaks. Open the nozzle until all air has been bled. Close the valve and nozzle. Rewind the hose. Open the nozzle to relieve the pressure in the hose.
Sign the service-label.

ARTICLE: 224851